




HTC Desire SD Card Replacement

Replace SD card in HTC Desire.

Written By: Hunter Kent





TOOLS:

- [Spudger](#) (1)



PARTS:

- [16 GB SD Card](#) (1)

Step 1 — Battery



- Insert flat end of spudger into slot on the top of phone to pry off the back plate.

Step 2



- Use flat edge of spudger to lift the bottom right corner of the battery.
- Lift the battery out of the phone.

Step 3 — SD Card



- Remove SD card and replace with a new one.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 08:04:45 AM.